



※ Quick Installation Guide ※

2



Smart Projector

Attention


- Please read this manual carefully before use and keep it for future reference.
- 1.The projector is non dustproof or waterproof.
 - 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
 - 3.Please use the original power adapter. The projector should work under specified rated power supply.
 - 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
 - 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
 - 6.Regularly clean projector vents, or dust may cause cooling malfunction.
 - 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
 - 8.Please handle with care during daily use.
 - 9.Please cut off the power if the projector is out of use for long time.
 - 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description


This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.



BT Air Remote




Bluetooth remote controller pairing




Note: the matching interface of Bluetooth remote control, Press "Voice input" button to bring up the matching guide.

Select your Language




App Store

In the App Store, applications can be installed with one click, and they can be used directly after installation. Our company also brings the applications to the market, enabling users to obtain and use them easily and conveniently.




Settings

Enter to Projection settings, Network settings, Bluetooth, Application Management, Language, Date and time, Other Setting, System information.



Projection Setting

Setting - Projector setting, enter to setup projection mode, Installation mode, digital scaling, Manual trapezoid.



Networking Setting

Setting - Networking Setting - WiFi setting, WiFi 'ON', select objective WiFi and input password to connect internet.



BT Setting

Settings - BT setting, BT "ON", click Refresh Device and choose objective device to pair.



Language Setting

Settings - Language Setting, enter to setup language and select input method.




Date And Time Setting

Setting - Date And Time Setting, enter to Date, Time and Use 24-hour format.




Other Setting

Setting - Other Setting, enter to get Power mode, Timed shutdown and Restore factory settings.



System information

Setting - System information, enter to UI version, resolution, Running memory and Storage space.



HDMI™ Signal


Ensure that Android devices(phone,pad,etc)are in the same local wireless LAN with these devices

Operations on Devices:
Home Screen→My Apps→ScreenCast→Open ScreenCast service
→Turn on the phone mirroring→Connection.




Screen saver

Setting - Other Setting - Screen saver, Screen saver time setting (The projection will enter screensaver mode at the set time without any operation or playback) , screensaver mode can be released by pressing the power button.



Wireless Screen

After connecting projector to other output device, enter HDMI or Audio/Video.



Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

Disclaimer

This manual is general instructions. The picture and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

 **Attention:**

Thanks for purchasing!

Need help?

Please send email or leave message to our Brand Support Team (support@nagcubic.com), in order to get better experience, prompt reply and further assistance.

Note: After a system upgrade, some text in the system may change slightly. As a result, the system text described in the manual may not fully match the text displayed on the device.

(ZX-E-N-H45020241015)



スマートプロジェクター

※クイック・インストール・ガイド※


ご注意ください

ご使用前にこの取扱説明書をよくお読みになり、万一の場合に備えて大切に保管してください。

1. プロジェクターは防塵・防水仕様ではありません。
2. 火災や感電の危険を減らすため、プロジェクターを雨や霧にさらさないでください。
3. 純正の電源アダプターをご使用ください。プロジェクターは指定された定格電源のもとでご使用ください。
4. プロジェクターが動作しているとき、レンズを直接見ないでください。強い光は目に閃光を与え、軽い痛みを引き起こす可能性があります。お子様がプロジェクターを使用する場合は、大人の監督のもとで行ってください。
5. プロジェクターの通風孔を塞がないでください。加熱はプロジェクターの寿命を縮め、危険の原因となります。
6. 定期的にプロジェクターの通風孔を清掃してください。そうしないと、ほこりが冷却不良の原因となることがあります。
7. プロジェクターは、油分の多い場所、湿気の多い場所、ほこりの多い場所、煙の多い場所では使用しないでください。油煙や化学薬品は故障の原因となります。
8. 日常的な取り扱いには十分ご注意ください。
9. プロジェクターを長期間使用しない場合は、電源を抜いてください。専門家以外の人が、テストやメンテナンスのためにプロジェクターを分解することは禁止されています。

構成説明


この取扱説明書参考用です。予告なしに変更される場合があります。Hotackは最終的な解釈の権利を留保します。



BTエアリモート




Bluetoothリモコンのペアリング




注意: Bluetoothリモコンのペアリングインターフェースで、「音声入力」ボタンを押すと、ペアリングガイドが表示されます。

言語を選択してください




アリストア

アリストアでは、アプリケーションをワンクリックでインストールでき、インストール後すぐに使用できます。当社アプリケーションを市場に提供し、ユーザーが簡単かつ便利に導いて使用できるようにしています。




設定

投影設定、ネットワーク設定、Bluetooth、アプリケーション管理、言語、日付と時刻、その他の設定、システム情報を選択します。



投影設定

設定>プロジェクター設定、投影モード、設定モード、デジタルスケーリング、手動整形の設定に入ります。




ネットワーク設定

設定>ネットワーク設定 WiFi設定、WiFiオン、目的のWiFiを選択し、パスワードを入力してインターネットに接続します。



BT設定

設定 - BT 設定、BT「オン」、デバイスの更新をクリックし、ペアリングする対象デバイスを選択します。



言語設定

設定 - 言語設定、入力方法を選択して言語を設定します。




日付と時刻の設定

設定 - 日付と時刻の設定、日付、時刻を入力し、24 時間形式を使用します。



その他の設定

設定 - その他の設定、入力すると、電源モード、時間指定シャットダウン、工場出荷時設定の復元が取得されます。




システム情報

設定 - システム情報、UIバージョン、解像度、実行メモリ、ストレージ容量に入る。




HDMI™ Signal

プロジェクターを他の出力デバイスに接続した後、HDMI またはオーディオ/ビデオに入ります。



スクリーンセーバー


設定 - 他の設定-スクリーンセーバー、スクリーンセーバー時間設定（設定した時間になると、操作や再生をしなくてもスクリーンセーバーモードになります）、スクリーンセーバーモードは電源ボタンを押すことで解除できます。



ワイヤレススクリーン

Android デバイス（スマートフォン、タブレットなど）がこれらのデバイスと同じローカル無線 LAN に接続されていることを確認してください。

デバイスでの操作：
ホーム画面 → アプリケーション → スクリーンキャスト → スクリーンキャストサービスを開く → スマートフォンミラーリングをオンにする → 接続する。



セキュリティについて

・プロジェクトターの操作とメンテナンスに関する重要な情報にご注意ください。問題を避けるために、この情報を注意深くお読みください。安全に関する指示を守ることで、プロジェクトターの寿命を延ばすことができます。

・設置やメンテナンスについては、資格者にご相談ください。また、損傷したワイヤ、アクセサリ、その他の周辺機器を使用しないでください。

・プロジェクトターは、可燃性、爆発性、強い電磁干渉（大型レーダー局、発電所、変電所）などから遠ざけてください。強い環境光（直射日光を避ける）など。

・プロジェクトターの通風孔を塞がないでください。

・純正の電源アダプターをご使用ください。

・プロジェクトターが過熱を避けるため、十分な換気を維持し、通気口が覆われていないことを確認してください。

・プロジェクトターが作動している時、レンズを直視しないでください。強い光が目に入り、軽い痛みを感じます。

・電源コードを折り曲げたり、引きずったりしないでください。

・電源コードをプロジェクターや重い物の下に置かないでください。

・電源コードを他の柔らかい素材で覆わないでください。

・電源コードを加熱しないでください。

・濡れた手で電源アダプターに触れないようにしてください。

免責事項

本取扱説明書は一般的な説明であり取扱説明書の写真や機能は実際の製品によって異なります。弊社は製品の性能向上に努めており、取扱説明書に記載されている製品の機能やインターフェースを前に通知なしに変更する権利を有します。

お使いのデバイスは大切に扱ってください。ソフトウェア/ハードウェアの誤用、修理、その他の理由による損害については、弊社では責任を負いかねます。また、第三者からのクレームによる損害についても責任を負いかねます。

本取扱説明書は専門エンジニアが念入りにチェックしたものですが、どうしても抜けがあることを了承ください。

「お買い上げありがとうございました。
お困りですか？」

製品名を明記の上、弊社ブランドサポートチームまでメールをお送りください。メールを送信してください。より良い体験を得るために、速な返信とさらなるサポートを提供します。

注記システムのアップグレード後、システム内の文言が若干変更される場合があります。そのため、説明書に記載されている文言が、実際の機器上の表示と一致しない可能性があります。

 構入りありがとうございます！
お手伝いが必要ですか？

ブランドサポートチーム (support@magcubic.com) にアイテム名添えてメールを送信してください。より良い体験を得るために、速な返信とさらなるサポートを提供します。

(ZX-E-N-HY45020241012)